

Do not use the FAST application while driving

How to Access

- Navigate to the the **FAST Landing Page**



- Under production, select “Live Dashboard”
https://bridges.txdot.kisters.cloud/eval/fast_dash.html
- Link the **Status Dashboard**

Status Dashboard

- All columns are sortable
- How long since flood information was updated
- Count of bridge warnings and road warnings impacted by forecasted flooding
- Type to search
- Click to view given row’s map

Dist Number	Abbreviation	Name	Last Update	Bridge Warnings	Road Warnings	Map Link
0	TEX	Texas (Entire State)	0h 42m	1757	1399	View Map
1	PAR	Paris	0h 50m	21	7	View Map
2	FTW	Fort Worth	0h 50m	114	47	View Map
3	WFS	Wichita Falls	0h 50m	1		View Map
4	AMA	Amarillo	0h 50m	1	1	View Map

Map

- A** Flood layers with visibility toggles
- B** Flood forecast model information
- C** Forecasted Flow data source
- D** Toggle menu ‘sidebar’ on/off
- E** Basemap and overlay map options
- F** Provide user feedback
- G** Disclaimer pop-up

Feedback
Comment Examples: “forecast at this important bridge is missing”
 “flood inundation limits in this area seem too big”
 “I wish the system could do ...”
 “System failed to load / crashed”